


HP OfficeJet Pro 8100 ePrinter - Blinking lights

The blinking lights on the OfficeJet Pro 8100 ePrinter control panel indicate the printer status and error conditions.



Callout	Description
1	Printhead icon (appears only when the printhead needs attention)
2	Cartridge Access Door icon (appears only when the cartridge access door or lid is open)
3	Out of Paper icon (appears only when the printer is out of paper)
4	Paper Jam icon (appears only when paper is jammed or the carriage is stalled)
5	Resume light and button
6	Cancel button
7	Power light and button
8	ePrint light and button
9	Wireless light and button
10	Wired Network (Ethernet) icon (appears only when the printer is connected to a wired network)
11	Wireless Network icon (appears only when the printer is connected to a wireless network or a wireless network is available)
12	Cartridge icons

[About](#) [Store](#)

[Gmail](#) [Images](#)



[Sign in](#)



[Google Search](#)

[I'm Feeling Lucky](#)

[Advertising](#)

[Business](#)

[How Search works](#)

[Applying AI towards science and the environment](#)

[Privacy](#)

[Terms](#)

[Settings](#)