

<STORING ONE TOUCH DIAL>

MENU
[] → ④ → ① →ONE TOUCH
KEY [] → ○ →

SET [] → ENTER NAME ○ → SET []

<STORING SPEED DIAL>

MENU
[] → ④ → ② →SPEED-DIAL ENTER NUMBER
○ ○ → ○ →

SET [] → ENTER NAME ○ → SET []

<SENDING A FAX>

SET DOCUMENT(S) [] → ENTER FAX NUMBER USING:
ONE TOUCH KEY [] OR SPEED DIAL KEY ○ OR REDIAL KEY ○ OR NUMERIC KEY ○ → PRESS START []

<FAX RECEPTION SETTING>

MODE KEY []	— MANUAL MODE	DISPLAY MAN -	FOR DEDICATED TELEPHONE USE
↓			
MODE KEY []	— FAX MODE	FAX -	FOR DEDICATED FAX USE
↓			
MODE KEY []	— FAX/TEL MODE	F/T -	FOR BOTH FAX & TELEPHONE USE
↓			
MODE KEY []	— TAD MODE	TAD -	WHEN CONNECTED TO TELEPHONE ANSWERING DEVICE

<PRINT OUT LIST/REPORT>

MENU
[] → ③ →
SELECT LIST/REPORT ○ → START []

TEST FAX

FOR
FAX TO SELF
(SAME MACHINE)
ATTEMPT 1