
MENU
ONE TOUCH
ENTER NUMBER
SET
ENTER NAME
SET
MENU
SET
<FAX RECEPTION SETTING>
DISPLAY
FAX
FOR DEDICATED FAX USE
MODE-KEY FAX ONLY
MODE-KEY FAX/TEL
F/T
FOR BOTH FAX & TELEPHONE USE
MODE-KEY MANUAL
MAN
FOR DEDICATED TELEPHONE USE
MC ON/OFF KEY
MC:MSG CTR
MC
FOR MESSAGE CENTER USE
<SENDING A FAX>
SET
DOCUMENT(S)
ENTER FAX NUMBER USING:
ONE TOUCH
OR
SPEED DIAL KEY
2-DIGIT NUMBER
OR
NUMERIC
KEY
PRESS
START